

THE 3 BASIC ELEMENTS OF PLUMBING

In order to plumb your vehicle with a minimum amount of time, effort and money, you should know the basics about hose, hose ends and adapter fittings.

Hose diameters are assigned AN numbers. Using your automotive hose size, choose from the chart below to find the AN equivalent for hose, hose ends and adapter fittings.

For example: a 3/8" standard hose equals -6 AN.

HOSE CONVERSIONS

STD. AUTOMOTIVE HOSE		AN EQUIVALENT
1/4"	=	-4
3/8"	=	-6
1/2"	=	-8
5/8"	=	-10
3/4"	=	-12
1"	=	-16
1-1/4"	=	-20
1-1/2"	=	-24


Another easy method to convert AN size to fractional is to remember that each AN number represents 1/16".

For example: -8 AN = 8/16" = 1/2".

TECHNICAL INFORMATION

MALE AN ADAPTER IDENTIFICATION CHART


The line drawings to the right depict actual sizes of the various common AN thread sizes by dash number. Lay your fitting over the appropriate drawing to determine what size fitting you have.



Male AN Adapter Chart

PIPE THREAD SIZE CHART

Use the diagram to the right to find pipe thread size. Place fitting against base line; read fitting size where it intersects the vertical line.




AN THREAD SIZES

AN SIZE	METAL TUBE O.D.	THREAD SIZE
-3	3/16"	3/8" - 24 SAE
-4	1/4"	7/16" - 20 SAE
-5	5/16"	1/2" - 20 SAE
-6	3/8"	9/16" - 18 SAE
-8	1/2"	3/4" - 16 SAE
-10	5/8"	7/8" - 14 SAE
-12	3/4"	1-1/16" - 12 SAE
-16	1"	1-5/16" - 12 SAE
-20	1-1/4"	1-5/8" - 12 SAE

B-NUT SIZE CHART

The line drawings to the right depict actual sizes of the various common types of fittings, hose ends and adapters. The number in parenthesis is SAE wrench size equivalent.




B-Nut Chart

1- CHOOSE HOSE SIZE



2- CHOOSE HOSE END STYLE

Straight, 45°, 90°, 120°, 150°, 180°
In same AN size as hose



3- CHOOSE ADAPTER


Adapt AN to NPT
Example: -6 AN to 3/8" NPT




= FINISHED PRODUCT




HOSE INSTALLATION TIPS



Avoid installing the hose in a twisted position.



Allow slack in your hose assembly for changes in length that occur under pressure.



When routing the hose assembly, provide a smooth bend radius. Avoid sharp bends, which will collapse the hose I.D. and could restrict flow.

HOSE ASSEMBLY TOOL

This handy tool separates the steel braid from the Teflon inner liner making insertion of the olive easier.

SIZE	PART #
-3 & -4	651970
-6 & -8	651971



HOW TO ASSEMBLE PROFLEX & PRORACE HOSE WITH FULL FLOW HOSE ENDS



Step One: Wrap hose tightly with race or electrical tape at the point determined for cut. Clamp the hose loosely in a vise close to the tape. Use a hacksaw with two blades opposing one another or abrasive cut-off wheel. Remove the tape when you are finished cutting.



Step Two: Unscrew the red socket of the hose end from the nipple. Hold the socket in a vise using soft jaws and insert the hose into the socket by turning it counterclockwise. The hose will stop at the bottom step of the socket.



Step Three: Position the nipple assembly of the hose end in the vise using soft jaws. Apply assembly lube to the threads of the socket as well as to the nipple assembly.



Step Four: Start the socket over the nipple by hand and tighten as far as possible by hand. Using an AN wrench, tighten until it reaches the nipple hex or when there is no more than 1/16" gap between the nipple/socket assembly. Be sure to wash & pressure test the assembly before using.

HOW TO ASSEMBLE PROCLASSIC HOSE WITH PROCLASSIC CRIMP HOSE ENDS



Step One: Cut hose to length, as straight and square as possible, with razor blade-type hose cutter or shears.



Step Two: Install the ProClassic Crimp Collar onto hose.



Step Three: Apply Russell Assembly Lube (or oil) onto barb assembly. Start barb assembly into hose; grasp hose behind collar & push hose onto barb assembly until it has fully bottomed out at collar's edge.



Step Four: Check collar/barb assembly to insure there is no gap (as shown by the arrow). If collar moves freely between hose and end fitting repeat step three.



Step Five: Make sure your die number is correct for hose you are crimping. Lift handle to top position opening dies. Place end assemble in dies. Align edge of the collar (at hose) with back face of dies, using over center action push down on handle until assembly releases from crimper. Inspect assembly, be sure to wash & pressure test prior to use.



Step Six: Completed hose assembly.

HOW TO ASSEMBLE PROCLASSIC HOSE WITH FULL FLOW HOSE ENDS



Step One: Cut hose to length, as straight and square as possible, with razor blade-type hose cutter or shears.



Step Two: Unscrew socket from hose end. Push hose into socket, turning counter-clockwise, until hose is seated against step in socket. Make sure rubber part of hose does not protrude into socket threads.




Step Three: Apply Russell assembly lube to threads on nipple assembly and in socket. Insert nipple into socket/hose and start threads by hand (clockwise).



Step Four: Hold socket/hose in vise. Turn nipple with wrench until there is less than 1/16" between nipple hex and socket. Repeat Steps 1-3 for other end of hose. Then, flush hose assembly with solvent or soapy water and blow clean with compressed air or let air dry.

HOW TO ASSEMBLE POWERFLEX HOSE & HOSE ENDS




Step One: Wrap the hose tightly with electrical or racers tape. Hold the hose firmly in a vise without crushing and cut through the tape. Make sure you make a straight cut. Remove the tape slowly and deburr the PTFE edges. Install the socket on the hose and slide it back out of the way.



Step Two: Insert the nipple portion of the PowerFlex hose end in a vise. Slip the hose over the nipple using a twisting motion to size the I.D. of the Teflon. Separate the wire braid from the O.D. of the PTFE tube with a small screwdriver. Be careful not to crush the Teflon.



Step Three: Push the olive sleeve around the PTFE and between the braid. This can be done by pushing the olive sleeve against the side of your workbench or vise. Be sure the PTFE liner is square to the bottom of the olive. With the nipple in the vise, lube the threads and the nipple portion of the hose end sparingly. Insert the hose over the nipple making sure the olive does not pop off the PTFE tube.



Step Four: Start the socket onto the nipple by hand. Tighten with a wrench until the gap between the nipple and the socket is no more than 1/16". Clean the hose assembly and pressure test before using.

HOW TO ASSEMBLE TWIST-LOK HOSE & HOSE ENDS



Step One: Cut hose to length using a sharp knife or shears.



Step Two: Liberally oil inside of hose & barbed end of hose end. Insert barbed end into hose using a twisting action. Put the swivel end at center hex in a vise. Use a twisting motion make bottom of hex even with hose edge, rubber insulator will cover end of hose.



Step Three: Completed hose assembly.